

			Bahnöffnungen
Sepia Tone	Soprano	# 5	1,4 mm
Sepia Tone	Soprano	# 6	1,5 mm
Sepia Tone	Soprano	# 7	1.6 mm
Sepia Tone	Alto	# 5	1,8 mm
Sepia Tone	Alto	# 6	1,9 mm
Sepia Tone	Alto	# 7	2,0 mm
Sepia Tone	Alto	# 8	2.1 mm
Sepia Tone	Tenor	# 7	2,4 mm
Sepia Tone	Tenor	# 8	2,6 mm
Sepia Tone	Tenor	# 9	2,85 mm
Sepia Tone	Bariton	# 7	2,6 mm
Sepia Tone	Bariton	# 7	2,85 mm
Sepia Tone	Bariton	# 7	3,00 mm
Sepia Tone	Klarinette	# 5	1,04 mm
Sepia Tone	Klarinette	# 6	1,15 mm

